


## Assembly instructions

All dimensions in this leafle t are stated in millimeters.


**WARNING** - Do not use any anti-friction oil or grease or thread-realese spray on ball bearing or on wheels with O-ring, it can cause the melting of the inside ball bearing grease, making them noisy or causing the break of the O-ring of the wheels.


The pictures and descriptions this leaflet contains are supplied for information purposes. The company reserves the right to in troduce those modifications it deems opportune for any construction or commercial need at any time and without advance notice.

W = width H = height
WA = door width I = distance between centres
L = length T = thickness
LB = rail length S = overlapping
D = depth









## Assembly instructions

